




## Adjusting the Bar Length

To achieve the feel of a shorter bar without having to go buy one, we've given riders the option of a simple adjustment on the bar.

Helpful Tools:

- Just your hands



Standard stock setting for lines attached to bar.



Pull up float to expose line ends.



Loosen lark heads loop...



And slip over knot. Pull bar line loop through hole to the other side as shown.



Slip lark heads over end knot.



Tighten and pull through bar end hole.



Slip float back over knot line.