




Adjusting for greater Depower Range

The Vario Cleat Adjuster on the 5th Element Bar allows you to get the most depower range out of your kite.

Simply adjust the Vario Cleat to your riding style preference before you leave the beach. The photo on the right shows the Depower strap and cleat in standard stock position.

Helpful Tools:

- Just your hands




Pull out the Cleat Positioning Tab.



To get the *most* depower range, slide the cleat higher on the depower line.



This increases the distance on the Depower Line from the bar to the cleat, allowing you to push bar farther away, thus increasing depower.



Secure Depower Line in cleat by re-inserting the Cleat Positioning Tab.



For more experienced riders, and riders looking for more constant power and less depower range, slide the cleat down toward the bar.



This decreases the distance on the Depower Line from the bar to cleat for minimal throw length and maximum steady power. However, by allowing for more Depower Line above the cleat, as shown here, you still have some depower capabilities.



This photo shows the Vario Cleat secured closest to the bar for minimal throw and maximum power as well, but with the Depower line pulled all the way through the Cleat. This allows for maximum depower at this cleat setting.